

Protec2 CLIQ padlock types

Council's new padlocks rolled out as part of the rekeying project will consist of two types of padlocks, the Protec2 CLIQ (electronic) and Protec2 (mechanical).

The CLIQ Padlock has a weather seal to protect the keyway and cylinder from the elements by keeping dust and water from the cylinders electronic and mechanical workings.

CLIQ - Padlock

1. Twist weather seal anti-clockwise to access the keyway.
2. Insert key, wait for the beep and key light to go green then turn the key in the cylinder to unlock.
3. Repeat the above step to lock.
4. Replace the weather seal and twist clockwise to seal the keyway.



Weather seal closed



Weather seal open

Note: The weather seal only works if it is returned to the locked position after the padlocks closed. Any damaged weather seals should be reported immediately.

Protec2 - Padlock

1. Insert key and then turn the key in the cylinder to unlock.
2. Repeat the above step to lock.



While the padlocks are open the key cannot be removed. Padlocks must be closed and locked to remove the key.

All padlocks will be tethered in place unless there is an extenuating circumstances.

For any issues please contact Community Safety and Innovation on 3810 6005.

Last Updated September 2020 - internal